

Vinyl Fitting Instructions

DRY METHOD

- 1. Essentially this is the same as above but without using water.
We suggest the use of masking tape markers or using the hinge method.**
- 2. To use the hinge method and with the backing paper still on the vinyl, place the vinyl against the panel in the correct position. Run a piece of masking tape running vertically down the sticker with enough extra to hold the vinyl in place against the panel.**
- 3. Gently fold one of the sides over and peel away the backing paper upto the masking tape. Cut away the backing paper without damaging the actual vinyl and apply the vinyl as per the wet method using an applicator. Once finished remove the masking tape and the remainder of the backing paper and continue fitting the vinyl.**
- 4. Gently peel away the premask (top application paper layer) to expose the fitted vinyl.**
- 5. Using a pin or scaple blade prick any trapped air bubbles.**
- 6. We suggest that you leave the vinyls for a minimum of 2 to 3 days (weather dependant) before washing the vehicle. Under no circumstances should the vehicle be used in a car wash. Use of a pressure washer is also not recommended. When drying the vehicle pat down the vinyls rather than rubbing across them as this can lead to leading edges lifting.**

The ideal temperature for applying vinyl is between 15 and 20 Degrees C.

DO NOT APPLY IN EXTREME WEATHER CONDITIONS.

Vinyl Creations Ltd cannot be held responsible for any damage to the vinyl or the vehicle caused by fitting our vinyls.