

## Vinyl Fitting Instructions

### WET METHOD

- 1. Ensure that the panel(s) are completely clean of all dirt, grease or road grime. We recommend the removal of any polish or wax from the panel as this will improve the strength of the glue.**
- 2. Offer up the vinyl so that you can get an idea for when you want it. Use masking tape markers if this will help.**
- 3. Using a water sprayer, apply a VERY fine mist of water to the panel.**
- 4. Remove the backing paper from the sticker.**
- 5. Place the vinyl onto the panel - remove and relay if necessary.**
- 6. Using a vinyl applicator or suitable credit card size piece of plastic gently but firmly rub the vinyl from the middle of the vinyl all the way up. Then rub from the same middle area all the way down. Perform this action (middle up, middle down) from the middle to the ends of the vinyl. This process helps to work out the water and also helps to eliminate any trapped air.**
- 7. Gently peel away the premask (top application paper layer) to expose the fitted vinyl.**
- 8. Using a pin or scaple blade prick any trapped air or large water bubbles.**
- 9. We suggest that you leave the vinyls for a minimum of 2 to 3 days (weather dependant) before washing the vehicle. Under no circumstances should the vehicle be used in a car wash. Use of a pressure washer is also not recommended. When drying the vehicle pat down the vinyls rather than rubbing across them as this can lead to leading edges lifting.**

**The ideal temperature for applying vinyl is between 15 and 20 Degrees C.**

**DO NOT APPLY IN EXTREME WEATHER CONDITIONS.**

**Vinyl Creations Ltd cannot be held responsible for any damage to the vinyl or the vehicle caused by fitting our vinyls.**