

Vinyl Removal Instructions

- 1. Warm up the panel and surface of the vinyl you wish to remove first. We suggest a heat gun or hair dryer. Do not burn yourself or over heat the panel or vinyl.**
- 2. Gently peel away the vinyl from the panel at as close to 180 degrees as possible. Continue to warm and peel as required.**
- 3. Remove any glue left behind using a relatively strong solvent cleaner.**

The ideal temperature for removing vinyl is the hotter the better. The colder it is the more the vinyl will shatter into small sections and take longer to remove. Old vinyl will also shatter - sadly there is nothing that can be done to speed up the removal of vinyl it is just down to time and patience.

Vinyl Creations Ltd cannot be held responsible for any damage to the vinyl or the vehicle caused by removing our vinyls.

VinylCreations

Units 31 & 32,
Church Road Business Centre
Sittingbourne
Kent. ME10 3RS
T: 01795 599123
F: 01795 599345
ideas@vinylcreations.co.uk
www.vinylcreations.co.uk